

## Tightening torques for ISO1/2/3 intermediate plates

## Intermediate plates

	ISO1 /Nm	ISO2 /Nm	ISO3 /Nm	Notes
Intermediate plates	3.1	3.5	5.6	4 Mounting screws
with pressure				and cord seal -> no
regulator				problem
Intermediate plates	3.1	3.5	5.6	-
with exhaust air	(Fixed with the	(Fixed with the	(Fixed with the	
throttle	valve screws)	valve screws)	valve screws)	
Intermediate plates	3.1	3.5	5.6	2 mounting screws
with pilot operated				and max. operating
non-return valves				pressure 8bar -> no
				problem
Intermediate plates	4.3	4	5.6	Moments according
with separate port 1			(tie rods take	to separate test
Intermediate plates			over force from	
with separate port 1			valve mounting	
and 14 of 1			screws)	

