

## Silencer for Safety valves XSz Installation & Maintenance Instructions

### Important Instructions

- Installation work must be carried out by authorised and qualified personnel
- Personnel must carefully read through and understand these instructions before starting work.
- In addition, the safety provisions of the Operating and installation instructions are by reading the „safety valves“ and Your safety must be observed!
- The person carrying out the work is responsible for proper installation. Norgren GmbH assumes no liability for this.
- Improper installation of the silencer goes out of all warranty claim.
- The check or ensure the functionality is transferred to the operator.
- Intervention or repair and maintenance measures on the safety valve, beyond the activities described in the instructions, may only be carried out by personnel of the manufacturer of the safety valve or by explicitly authorized and trained by it.

### Safety caution:



- Before starting installation work, make sure the system is depressurised and does not carry live voltage.
- If flanges are not fastened correctly, there is risk to life, limb and property from loose (flying) parts!

### Safety caution:



- Dismantle only when system is depressurised!

IMI International s.r.o.

Evropská 852  
664 42 Modřice  
Czech Republic  
www.imiplc.com

The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The given information does not release the user from the obligation of own judgement and verification. It must be remembered that our products are subject to a natural process of wear and aging. © This document, as well as the data, specifications and other informations set forth in it, are the exclusive property of Norgren GmbH. Without their consent it may not be reproduced or given to third parties.

Subject to modifications.  
These instructions were originally generated in German.

Order no: 7503632000000050  
DE/EN  
Revision: C

### Silencer 0016422



### Delivery contents:

**0016422**  
1x Silencer  
2x socket head screws M5


### Installation

- The mounting screws accordance with the following specification Torque tighten:



Silencer **0016422**  
socket head screws M5  
4,5 +/- 0,5 Nm

Supply use the included original screws only !



2 x M5 screws  
4,5 +/- 0,5 Nm

### Silencer 0016622



### Delivery contents:

**0016622**  
1x Silencer  
4x socket head screws M10


### Installation

- The mounting screws accordance with the following specification Torque tighten:



Silencer **0016622**  
socket head screws M10  
10 +2 Nm

Supply use the included original screws only !



4x M10 screws  
10 +2 Nm

### Servicing

Intervall	Activity
After 1 million switching operations, at least once per year	Tightening torque of the fixing screws and tighten the silencer check according to the specification.

### Disposal

Dispose of packaging and used parts as required by the regulations in the country of use.